

# WEATHER STATION MANUAL

## Thermometer

Thermometers are operated by sensitive mechanisms that respond to air temperature changes. Each mechanism has been adjusted after manufacture and will accurately read room temperature if properly located.

Place the thermometer in area where known temperature can be determined for 90 minutes. In case the reading does not agree, make necessary adjustment using a screw- driver, through the adjustment slot at the back of the instrument.