


DST AUTO WALL CLOCK (USA)


First-Time Usage Setup:

1. Insert one fresh AA size 1.5V battery, ensuring the right polarity. The positive end (+) of the battery should be inserted first.

2. When  appears on the screen, press ▲ to adjust the second hand to 12

(If holds ▲, the second hand will go sweeping) Then turn the time adjusting knob to set hour/minute hands at 12 o'clock.

Press MODE key and it appears



Note: If your country is without DST, press ▼ to change ON to OF(OFF)

3. Press MODE key and it appears




Press ▲▼ to set for correct year.

4. Press MODE key and it appears



Press ▲▼ to set for correct month.

5. Press MODE key and it appears




Press ▲▼ to set for correct date.

6. Press MODE key and it appears



Press ▲▼ to set for correct hour.

7. Press MODE key and it appears



Press ▲▼ to set for correct minute.

8. Press MODE key to complete all the setting. Then, the hour/minute/second hands will start sweeping to the same time as the LCD setting time.

Note: If your setting data is wrong and goes to the next mode, remove the battery and set again.

Adjust LCD Display Mode:

Press MODE key to choose the display mode you want. There are three modes as below:


Day
Date

or


Hour
Minute

or

Month
Date



OR



OR

